

## 2.16 Definitions - P

**Performance Index:** An index, described in ISO Procedures, that tracks a Generator's response to AGC signals from the ISO.

**Performance Tracking System:** A system designed to report metrics for Generators and Loads which include but are not limited to actual output and schedules. This system is used by the ISO to measure compliance with criteria associated with the provision of Energy and Ancillary Services.

**Point-to-Point Transmission Service:** The reservation and transmission of Capacity and Energy on ~~either a firm or non-firm~~ basis from the Point(s) of Receipt to the Point(s) of Delivery under [the ISO Tariffs](#) ~~Part 3 of the ISO OATT~~.

**Point(s) of Delivery:** Point(s) on the NYS Transmission System or Proxy Generator Buses where Energy transmitted by the ISO will be made available to the Transmission Customer under the OATT. The Point(s) of Delivery shall be specified pursuant to ISO Procedures.

**Point(s) of Injection (“POI” or “Point of Receipt”):** The point(s) on the NYS Transmission System or Proxy Generator Buses where Energy, Capacity and Ancillary Services will be made available to the ISO by the delivering party under the ISO OATT or the ISO Services Tariff. (May be referred to as “Point of Receipt” or similar in some Existing Transmission Agreements.)

**Point(s) of Receipt:** Point(s) of interconnection on the NYS Transmission System or Proxy Generator Buses where Energy will be made available to the ISO by the Transmission Customer under the OATT. The Point(s) of Receipt shall be specified pursuant to ISO Procedures.

**Point(s) of Withdrawal (“POW” or “Point of Delivery”):** The point(s) on the NYS Transmission System or Proxy Generator Buses where Energy, Capacity and Ancillary Services will be made available to the receiving party under the ISO OATT or the ISO Services Tariff. (May be referred to as “Point of Delivery” or similar in some Existing Transmission Agreements.)

**Pool Control Error (“PCE”):** The difference between the actual and scheduled interchange with other Control Areas, adjusted for frequency bias.

**Post Contingency:** Conditions existing on a system immediately following a Contingency.

**Power Exchange (“PE”):** A commercial entity meeting the requirements for service under the ISO OATT or the ISO Services Tariff that facilitates the purchase and/or sale of Energy, Unforced Capacity and/or Ancillary Services in a New York Wholesale Market. A PE may transact with the ISO on its own behalf or as an agent for others.

**Power Factor:** The ratio of real power to apparent power (the product of volts and amperes, expressed in megavolt-amperes, MVA).